

Project:	
Type:	
Catalog #:	



Instant Fit: Simply remove the existing T8 fluorescent lamps and replace with Smart Drive LED tubes, which will run off the existing ballast. There are no special instructions and no tools are required. Choose Smart Drive Tubes for: Quick and Easy Installation - T5, T8 and T12 Retrofits - Upgrades for T8 Existing Fluorescent Fixtures

- * Call for lumens
- * Call to check DLC listing

Direct Drive: DirectDrive LED tubes eliminate the need for an external driver or ballast. For new construction installations, simply connect the 120-277V line voltage directly to the sockets. For retrofit installations, bypass the existing ballast by cutting the wires and connecting the 120-277V line voltage directly to the sockets. No ballast or driver is required

Call for different wattages, sizes, colors.

Specifications Subject To Change Without Notice